

Product

Information

CZC18
2CPX052469R9999

CZC18 Copper busbar connection set, 223 mm x 350 mm x 106 mm

CZC8
2CPX052468R9999

CZC8 Copper busbar connection set, 223 mm x 350 mm x 106 mm

CZC14
2CPX052467R9999

CZC14 Copper busbar connection set, 232 mm x 75 mm x 115 mm

CZC4
2CPX052466R9999

CZC4 Copper busbar connection set, 232 mm x 75 mm x 115 mm

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Россия +7(495)268-04-70

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://abbenclosures.nt-rt.ru/> || aua@nt-rt.ru

Product	Information
<input type="checkbox"/> CZE35 2CPX052566R9999	CZE35 ComfortLine Feed-in enclosure, Surface mounting, Isolated (Class II), IP44, Rows: 0, 950 mm x 550 mm x 215 mm
<input type="checkbox"/> CZE623 2CPX052551R9999	CZE623 ComfortLine Feed-in enclosure, Isolated (Class II), IP54, 500 mm x 300 mm x 215 mm
<input type="checkbox"/> CZE622 2CPX052550R9999	CZE622 ComfortLine Feed-in enclosure, Isolated (Class II), IP54, 500 mm x 300 mm x 215 mm
<input type="checkbox"/> CZE57 2CPX052495R9999	CZE57 ComfortLine Accessory feeding, Horizontal, 401 mm x 188 mm x 104 mm
<input type="checkbox"/> CZE56 2CPX052494R9999	CZE56 ComfortLine Accessory feeding, Horizontal, 391 mm x 188 mm x 91 mm
<input type="checkbox"/> CZE58 2CPX052496R9999	CZE58 ComfortLine Accessory feeding, Horizontal, 401 mm x 188 mm x 104 mm
<input type="checkbox"/> CZE63 2CPX052490R9999	CZE63 ComfortLine Accessory feeding, 24 mm x 92 mm x 113 mm
<input type="checkbox"/> CZE62 2CPX052493R9999	CZE62 ComfortLine Accessory feeding, 33 mm x 227 mm x 86 mm
<input type="checkbox"/> CZE64 2CPX052492R9999	CZE64 ComfortLine Accessory feeding, 232 mm x 22.5 mm x 91 mm
<input type="checkbox"/> CZE60 2CPX052491R9999	CZE60 ComfortLine Accessory feeding, 190 mm x 96 mm x 90 mm
<input type="checkbox"/> CZE34 2CPX052481R9999	CZE34 ComfortLine Feed-in enclosure, Surface mounting, Isolated (Class II), IP44, Rows: 0, 950 mm x 300 mm x 215 mm
<input type="checkbox"/> CZE33 2CPX052482R9999	CZE33 ComfortLine Feed-in enclosure, Surface mounting, Isolated (Class II), IP44, Rows: 0, 950 mm x 550 mm x 215 mm
<input type="checkbox"/> CZE32 2CPX052478R9999	CZE32 ComfortLine Feed-in enclosure, Surface mounting, Isolated (Class II), IP30, Rows: 0, 950 mm x 300 mm x 215 mm
<input type="checkbox"/> CZE31 2CPX052479R9999	CZE31 ComfortLine Feed-in enclosure, Surface mounting, Isolated (Class II), IP30, Rows: 0, 950 mm x 300 mm x 215 mm

Product	Information
<input type="checkbox"/> CZE12 2CPX052475R9999	CZE12 ComfortLine Feed-in enclosure, Isolated (Class II), IP44, 500 mm x 450 mm x 215 mm
<input type="checkbox"/> CZE30 2CPX052477R9999	CZE30 ComfortLine Feed-in enclosure, Surface mounting, Isolated (Class II), IP30, Rows: 0, 650 mm x 300 mm x 215 mm
<input type="checkbox"/> CZE230 2CPX052471R9999	CZE230 ComfortLine Feed-in enclosure, Isolated (Class II), IP31, 500 mm x 250 mm x 165 mm
<input type="checkbox"/> CZE220 2CPX052470R9999	CZE220 ComfortLine Feed-in enclosure, Isolated (Class II), IP31, 250 mm x 250 mm x 165 mm
<input type="checkbox"/> CZE130 2CPX052472R9999	CZE130 ComfortLine Feed-in enclosure, Isolated (Class II), IP44, 500 mm x 300 mm x 215 mm
<input type="checkbox"/> CZE11 2CPX052474R9999	CZE11 ComfortLine Feed-in enclosure, Isolated (Class II), IP44, 500 mm x 300 mm x 215 mm
<input type="checkbox"/> CZE130US 2CPX052473R9999	CZE130US ComfortLine Feed-in enclosure, Isolated (Class II), IP44, 500 mm x 300 mm x 215 mm

Product Information

CZL63 2CPX052693R9999	CZL63 ComfortLine Compact CU , Copper
CZL61 2CPX052449R9999	CZL61 ComfortLine Compact CA Enclosure accessories, 15 mm x 200 mm x 300 mm
CZL60 2CPX052448R9999	CZL60 ComfortLine B Earthing set, 15 mm x 125 mm x 280 mm

CZF4
2CPX052438R9999 CZF4 ComfortLine Flange, 22 mm x 223 mm x 106 mm

CZF1
2CPX052435R9999 CZF1 ComfortLine Flange, 22 mm x 223 mm x 106 mm

CZF3
2CPX052437R9999 CZF3 ComfortLine Flange, 22 mm x 223 mm x 106 mm

CZF2
2CPX052436R9999 CZF2 ComfortLine Flange, 22 mm x 223 mm x 106 mm

CZF11
2CPX052441R9999 CZF11 ComfortLine Flange, 4.5 mm x 220 mm x 114 mm

CZF18
2CPX052445R9999 CZF18 ComfortLine Flange, 26 mm x 220 mm x 114 mm

CZF14
2CPX052444R9999 CZF14 ComfortLine Flange, 4.5 mm x 220 mm x 114 mm

CZF13
2CPX052443R9999 CZF13 ComfortLine Flange, 4.5 mm x 220 mm x 114 mm

CZF10
2CPX052440R9999 CZF10 ComfortLine Flange, 4.5 mm x 220 mm x 114 mm

CZF12
2CPX052442R9999 CZF12 ComfortLine Flange, 4.5 mm x 220 mm x 114 mm

CZF155
2CPX054409R9999 CZF155 ComfortLine Flange, 4.5 mm x 220 mm x 114 mm

CZF175
2CPX054410R9999 CZF175 ComfortLine Flange, 4.5 mm x 220 mm x 114 mm

CZF255
2CPX054411R9999 CZF255 ComfortLine Flange, 4.5 mm x 220 mm x 114 mm

CZF17
2CPX052549R9999 CZF17 ComfortLine Flange, 50 mm x 220 mm x 215 mm

CZF1B
2CPX052447R9999 CZF1B ComfortLine Enclosure accessories, 22 mm x 223 mm x 106 mm

CZF1D
2CPX052555R9999 CZF1D ComfortLine Flange, 17 mm x 192.5 mm x 79.5 mm

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новыйорск (3496)41-32-12
Киров (8332)68-02-04
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47